

COM-99
INSTALLATION AND OPERATION
MANUAL

Version 1.0 7/87

IMPORTANT

READ Section II - COM-99 Installation Guide and
see FIGURE 4 (Mounting & Hook-Up) BEFORE beginning
Installation.

TABLE OF CONTENTS

<u>DESCRIPTION</u>	<u>PAGE</u>
Introduction	
System Description	1 - 2
Specifications	3
Programming Ranges	4 - 5
Section I Description of Control Strategies	
General Information	6 - 7
Time of Day Control	8
Dewpoint Control	9 - 10
FIGURE 1	
KW Monitoring and Demand Control	11 - 13
FIGURE 2	
Temperature Logging	14
Alarms	15 - 16
Alarm Logs	16 - 17
Elapsed Time	18
Load Status	19
Dial Out	20
Section II COM-99 Installation Guide	
Mounting the Unit	21
Power and Load Wiring	21 - 23
FIGURES 3 - 13	
Section III COM-99 Programming Guide	
Master Clearing the System	24 - 25
Programming Mode	25 - 28
Programming Load ON/OFF Times	29 - 33
FIGURE 14	
Holiday Programming	34
Programming the Dewpoint Control	35 - 38
Programming for KW Monitoring	39 - 40
Programming for KW Monitoring & Demand Control	41 - 43
KW Constants	44
Alarm Setpoints	45 - 48
Section IV Trouble Shooting Guide	
COM-99 Time of Day Control	49 - 54
Trouble Shooting Checklist	55 - 56
APPENDIX A Quick Keyboard Guide Sheets	57 - 61
APPENDIX B Scheduling Sheets	62 - 64

FIGURES

FIGURE 1	DEWPOINT CONTROLLED LOAD
FIGURE 2	LOAD SHEDDING ON DEMAND SETPOINT
FIGURE 3	COMPONENT LOCATION DIAGRAM
FIGURE 4	MOUNTING & HOOK-UP
FIGURE 5	POWER MONITORING
FIGURE 6	INSTALLATION OF SENSORS
FIGURE 7	LOAD HOOK-UP
FIGURE 8	DIGITAL INPUT CONNECTION
FIGURE 9	DPC-1
FIGURE 10	SUPERMARKET SYSTEMS
FIGURE 11	COMPONENT REFERENCE
FIGURE 12	SAMPLE BUILDING LAYOUT
FIGURE 13	TYPICAL WALL PLACEMENT
FIGURE 14	COM-99 KEYPAD

INTRODUCTION

